




Engraving Jig Instructions for: *The Personalised Touch* CARD1 Business & Credit Card Holder

***ALWAYS ensure the Centre Origin Point is correct before engraving.**
User's Manual Page 76 and C:\Program Files\METAZASoftware\Samples\Axis.mzs



1. Install the Universal Jig into the vice and position the yellow pegs as you see in the image above and below.
2. Rotate the Cardholder 90° clockwise so the hinge is on the right hand side and secure by closing the vice, clamping the gift securely, squarely and as flat as possible.



3. Open "CARD1.mzs" MZS Template found on the Metaza.com CD or website.
4. Import Image/Text/Logo and proceed to engrave following the MPX-80's User Manual.

It is advised that this item should NOT be engraved without using the green protective nose cone.

Please note that different materials require different Brightness/Contrast/Gamma levels within PrintPreview mode.